



PROGRAM BC60, BC80, BC120, BC220, BC230

1. Turn on scanner.
2. Press MANUAL.
3. For 100 or 200 channel scanner, type in Car #. (For 10 or 50 channel scanner, press Channel #.)
4. Press MANUAL.
5. Type in frequency.
6. Press "E" for ENTER.
7. Repeat Steps 2 thru 6.