



PROGRAM RP6150

1. Turn on scanner.
2. Press MANUAL.
3. Enter Channel/Car #.
4. Press PGM.
5. Enter Frequency
6. Press ENTER.
7. Repeats steps 2 thru 6 for the rest of the channels

NOTE: If ERROR appears, press CLEAR and continue.

PROGRAM RP6198

1. Turn on scanner.
2. Press MANUAL.
3. Press PROG.
4. Enter Frequency numbers.
5. Press ENT.
6. Enter Car #.
7. Press ENT.